

Fan/light controls



Dimmer (top)

- Tap on to favorite light level; tap off
- Tap twice for full on
- Touch rocker to adjust light level

Fan control (bottom)

- Tap on to favorite fan speed; tap off
- Touch rocker to adjust fan speed
- 7 quiet fan speeds, plus off, provide enhanced comfort
- Designed to prevent motor hum
- For use with only one fan/light

Canopy modules

(fan mounted)



- For use only in multi-fan applications with MA-FQ4FM; see pg. 58
- Order one canopy module for each additional fan controlled
- Use up to three additional fan-mounted canopy modules for up to four fans total (controlled as one group)

✂ Fan controls

Canopy modules (fan-mounted)

Canopy module	CM-FQ1
120V 1A	

All Maestro fan controls and fan/light controls include one canopy module for control of one fan.

One additional canopy module (CM-FQ1) required for each additional fan—up to four fans total.

✂ Fan/light controls

Fan/light control—quiet 7-speed

Single-pole	MA-LFQHW-WH
120V 300W light (top)	
Incandescent/halogen	
1 canopy module for up to 1 A fan (bottom)	

Multi-location	MA-LFQM- XX ¹
120V 300W light (top)	
Incandescent/halogen	
1 canopy module for up to 1 A fan (bottom)	

All above include the necessary wall-mounted fan/light control and one fan-mounted canopy module.

Single-pole model includes wallplate.

Multi-location model may be used with up to two companion fan/light controls (MA-ALFQ35-), see pg. 60. Wallplates sold separately.

No derating required if ganged.

XX¹: Gloss and Satin Color® codes, see pg. 50
(Wallplates not included. Order separately, see pg. 169)

All models must be derated if ganged unless otherwise noted, see pg. 179.