

Obsolete and Replacement Part Numbers for Small Pack Terminals

X-Packs	Retiring Part Number	Replacement Part Number	Part Description	Wire Size (AWG)	Stud/Tab Size (in.)
	BSV10X-X	BSV10X-E	Butt Splice	12-10	
	BSV14X-X	BSV14X-E	Butt Splice	16-14	
	BSV18X-X	BSV18X-E	Butt Splice	22-18	
	BSV18X-XY	BSV18X-E	Butt Splice	22-18	
	DNF14-250-X	DNF14-250-E	Female Disconnect	16-14	.250" x .032"
	DNF18-250-X	DNF18-250-E	Female Disconnect	22-18	.250" x .032"
	DV10-250M-X	DNF10-250FIMB-E	Female Disconnect	12-10	.250" x .032"
	DV10-250-X	DV10-250-E	Female Disconnect	12-10	.250" x .032"
	DV14-250MB-X	DV14-250MB-E	Male Disconnect	16-14	.250" x .032"
	DV14-250P-X	DV14-250P-E	Piggyback Disconnect	16-14	.250" x .032"
	DV18-250MB-X	DNF18-250FIM-E	Male Disconnect	22-18	.250" x .032"
	DV18-250MB-XY	DNF18-250FIM-E	Male Disconnect	22-18	.250" x .032"
	JN218-216-X	JN218-216-C	Wire Joint	22-14	
	JN418-212-X	JN418-212-C	Wire Joint	18-12	
	P10-10F-X	P10-10F-L	Fork Terminal	12-10	#10
	P10-10R-X	P10-10R-E	Ring Terminal	12-10	#10
	P14-10R-X	P14-10R-E	Ring Terminal	16-14	#10
	P14-6F-X	P14-6F-C	Fork Terminal	16-14	#6
	P14-8F-X	P14-8F-E	Fork Terminal	16-14	#8
	P18-10R-X	P18-10R-C	Ring Terminal	22-18	#10
	P18-6F-X	P18-6F-C	Fork Terminal	22-18	#6
	PV10-10F-X	PV10-10F-E	Fork Terminal	12-10	#10
	PV10-10LF-X	PV10-10LF-E	Locking Fork Terminal	12-10	#10
	PV10-10R-X	PV10-10R-E	Ring Terminal	12-10	#10
	PV10-14F-X	PV10-14F-E	Fork Terminal	12-10	1/4"
	PV10-14LF-X	PV10-14LF-L	Locking Fork Terminal	12-10	1/4"
	PV10-14R-X	PV10-14R-E	Ring Terminal	12-10	1/4"
	PV10-8F-X	PV10-8F-E	Fork Terminal	12-10	#8
	PV10-8LF-X	PV10-8LF-E	Locking Fork Terminal	12-10	#8
	PV10-8R-X	PV10-8R-E	Ring Terminal	12-10	#8
	PV14-10F-X	PV14-10F-E	Fork Terminal	16-14	#10
	PV14-10LF-X	PV14-10LF-E	Locking Fork Terminal	16-14	#10
	PV14-10R-X	PV14-10R-E	Ring Terminal	16-14	#10
	PV14-610R-X	PV14-610R-C	Multi-Stud Ring Terminal	16-14	#6-#10
	PV14-6F-X	PV14-6F-E	Fork Terminal	16-14	#6
	PV14-6LF-X	PV14-6LF-E	Locking Fork Terminal	16-14	#6
	PV14-6R-X	PV14-6R-E	Ring Terminal	16-14	#6
	PV14-8F-X	PV14-8F-E	Fork Terminal	16-14	#8
	PV14-8LF-X	PV14-8LF-E	Locking Fork Terminal	16-14	#8
	PV14-8R-X	PV14-8R-E	Ring Terminal	16-14	#8
	PV18-10F-X	PV18-10F-E	Fork Terminal	22-18	#10
	PV18-10F-XY	PV18-10F-E	Fork Terminal	22-18	#10

PV18-10LF-X	PV18-10LF-CY	Locking Fork Terminal	22-18	#10
PV18-10LF-XY	PV18-10LF-CY	Locking Fork Terminal	22-18	#10
PV18-10R-X	PV18-10R-E	Ring Terminal	22-18	#10
PV18-10R-XY	PV18-10R-E	Ring Terminal	22-18	#10
PV18-610R-X	PV18-610R-C	Multi-Stud Ring Terminal	22-18	#6-#10
PV18-610R-XY	PV18-610R-C	Multi-Stud Ring Terminal	22-18	#6-#10
PV18-6F-X	PV18-6F-E	Fork Terminal	22-18	#6
PV18-6F-XY	PV18-6F-E	Fork Terminal	22-18	#6
PV18-6R-X	PV18-6R-E	Ring Terminal	22-18	#6
PV18-6R-XY	PV18-6R-E	Ring Terminal	22-18	#6
PV18-8F-X	PV18-8F-E	Fork Terminal	22-18	#8
PV18-8F-XY	PV18-8F-E	Fork Terminal	22-18	#8
PV18-8LF-X	PV18-8LF-E	Locking Fork Terminal	22-18	#8
PV18-8LF-XY	PV18-8LF-E	Locking Fork Terminal	22-18	#8
PV18-8R-X	PV18-8R-E	Ring Terminal	22-18	#8
PV18-8R-XY	PV18-8R-E	Ring Terminal	22-18	#8

Mid-Packs	<u>Retiring Part</u>	<u>Replacement Part</u>	<u>Part Description</u>	<u>Wire Size</u> (AWG)	<u>Stud/Tab Size</u> (in.)
	Number	Number			
	DNF14-250FIB-L	DNF14-250FIB-E	Female Disconnect	16-14	.250" x .032"
	DNF18-250FIB-L	DNF18-250FIB-E	Female Disconnect	22-18	.250" x .032"
	DV10-250-Q	DV10-250-E	Female Disconnect	12-10	.250" x .032"
	DV14-250B-L	DV14-250B-E	Female Disconnect	16-14	.250" x .032"
	DV18-250B-L	DV18-250B-E	Female Disconnect	22-18	.250" x .032"
	DV18-250B-LY	DV18-250B-E	Female Disconnect	22-18	.250" x .032"
	P10-10F-Q	P10-10F-L	Fork Terminal	12-10	#10
	P10-10R-Q	P10-10R-E	Ring Terminal	12-10	#10
	P10-6F-Q	P10-6F-L	Fork Terminal	12-10	#6
	P10-6R-Q	P10-6R-L	Ring Terminal	12-10	#6
	P10-8F-Q	P10-8F-L	Fork Terminal	12-10	#8
	P10-8R-Q	P10-8R-L	Ring Terminal	12-10	#8
	P14-10F-L	P14-10F-C	Fork Terminal	16-14	#10
	P14-10R-L	P14-10R-E	Ring Terminal	16-14	#10
	P14-6F-L	P14-6F-C	Fork Terminal	16-14	#6
	P14-6R-L	P14-6R-C	Ring Terminal	16-14	#6
	P14-8F-L	P14-8F-E	Fork Terminal	16-14	#8
	P14-8R-L	P14-8R-C	Ring Terminal	16-14	#8
	P18-10F-L	P18-10F-C	Fork Terminal	22-18	#10
	P18-10R-L	P18-10R-C	Ring Terminal	22-18	#10
	P18-6F-L	P18-6F-C	Fork Terminal	22-18	#6
	P18-6R-L	P18-6R-C	Ring Terminal	22-18	#6
	P18-8F-L	P18-8F-C	Fork Terminal	22-18	#8
	P18-8R-L	P18-8R-C	Ring Terminal	22-18	#8
	PV10-10F-Q	PV10-10F-E	Fork Terminal	12-10	#10
	PV10-10LF-Q	PV10-10LF-E	Locking Fork Terminal	12-10	#10
	PV10-10R-Q	PV10-10R-E	Ring Terminal	12-10	#10
	PV10-14R-Q	PV10-14R-E	Ring Terminal	12-10	1/4"
	PV10-8F-Q	PV10-8F-E	Fork Terminal	12-10	#8

PV10-8LF-Q	PV10-8LF-E	Locking Fork Terminal	12-10	#8
PV14-10F-L	PV14-10F-E	Fork Terminal	16-14	#10
PV14-10LF-L	PV14-10LF-E	Locking Fork Terminal	16-14	#10
PV14-10R-L	PV14-10R-E	Ring Terminal	16-14	#10
PV14-6F-L	PV14-6F-E	Fork Terminal	16-14	#6
PV14-6LF-L	PV14-6LF-E	Locking Fork Terminal	16-14	#6
PV14-6R-L	PV14-6R-E	Ring Terminal	16-14	#6
PV14-8F-L	PV14-8F-E	Fork Terminal	16-14	#8
PV14-8LF-L	PV14-8LF-E	Locking Fork Terminal	16-14	#8
PV14-8R-L	PV14-8R-E	Ring Terminal	16-14	#8
PV18-10F-L	PV18-10F-E	Fork Terminal	22-18	#10
PV18-10F-LY	PV18-10F-E	Fork Terminal	22-18	#10
PV18-10LF-L	PV18-10LF-CY	Locking Fork Terminal	22-18	#10
PV18-10LF-LY	PV18-10R-CY	Locking Fork Terminal	22-18	#10
PV18-10R-L	PV18-10R-E	Ring Terminal	22-18	#10
PV18-10R-LY	PV18-10R-E	Ring Terminal	22-18	#10
PV18-6F-L	PV18-6F-E	Fork Terminal	22-18	#6
PV18-6F-LY	PV18-6F-E	Fork Terminal	22-18	#6
PV18-6LF-L	PV18-6LF-E	Locking Fork Terminal	22-18	#6
PV18-6LF-LY	PV18-6LF-E	Locking Fork Terminal	22-18	#6
PV18-6R-L	PV18-6R-E	Ring Terminal	22-18	#6
PV18-6R-LY	PV18-6R-E	Ring Terminal	22-18	#6
PV18-8F-L	PV18-8F-E	Fork Terminal	22-18	#8
PV18-8F-LY	PV18-8F-E	Fork Terminal	22-18	#8
PV18-8LF-L	PV18-8LF-E	Locking Fork Terminal	22-18	#8
PV18-8LF-LY	PV18-8LF-E	Locking Fork Terminal	22-18	#8
PV18-8R-L	PV18-8R-E	Ring Terminal	22-18	#8
PV18-8R-LY	PV18-8R-E	Ring Terminal	22-18	#8