



# Motor Protection Circuit Breakers and Motor Circuit Protectors

## Accessories

Description		For Use With	Pkg. Quantity	Cat. No.
	<b>Terminal End Cover — 0.25 in.</b>	140M-I	1	140U-I-TC2
	<b>Terminal End Cover — 0.41 in.</b>			140U-I-TC4
	<b>Terminal Shields (Plastic)</b> IP20 Ingress Protection	140M-I	1	<b>140U-I-TS1</b>
	<b>Padlockable Handle Lock Hasp</b> — Off only Padlocking Hasp Lock-OFF only	140M-I	1	<b>140U-I-PL</b>
	<b>End Cap Kit</b> Provides 3-phase connections for terminal or bolt-on connections Metric Hardware	140M-I	1	<b>140U-I-ECM</b>
	<b>Phase Barriers</b> Provides additional phase clearance when special connections are required	140M-I	2	<b>140U-I-PB</b>
	<b>Terminal Lugs</b> Steel Terminal Copper/Aluminum wire #4-4/0 AWG	140M-I	3	<b>140U-I-TLS1</b>
	<b>Terminal Lugs</b> Stainless Steel Terminal Copper/Aluminum wire #4-4/0 AWG			<b>140U-I-TLS2</b>
	<b>Rotary Close Couple Handle</b> International Black handle	140M-I	1	<b>140U-I-RCB</b>
	<b>Rotary Close Couple Handle</b> International Red/Yellow handle			<b>140U-I-RCR</b>
	<b>Operating Mechanism for External Handles</b>	140M-I	1	<b>198-H2</b>
	<b>External Handles</b> Black/Grey IP66 (Type 3/3R/4/4X/12)	140M-I	1	<b>190-HM4</b>
	Red/Yellow IP66 (Type 3/3R/4/4X/12)			<b>190-HM4E</b>
	Black/Grey IP55 (Type 1)			<b>190-HM1</b>
	Red/Yellow IP55 (Type 1)			190-HM1E
	<b>Overload Pre-trip Auxiliary Contact (AX)</b> Opens contactor coil circuit on overload before MPCB trips (Automatic reset)	140M-J, -L (MPCB only)	1	<b>140U-J-ER1RX</b>